



## CE Kit

### Groundsmaster® 7200/7210 Traction Unit with 60-inch Side Discharge Mower

Model No. 117-9248

## Installation Instructions


**Note:** Determine the left and right sides of the machine from the normal operating position.

# Safety

## Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.



106-6754

1. Warning—do not touch the hot surface.
2. Cutting/dismemberment hazard, fan and entanglement hazard, belt—stay away from moving parts.



112-1689

1. Tipping hazard—do not operate on slopes greater than 14 degrees.

# Installation

## Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
<b>1</b>	Latch locator bracket	1	Install the locking latch.
	Bolt (5/16 x 3/4 inch)	1	
	Lock nut (5/16 inch)	1	
	Locking latch	1	
	Hood support	1	
	Bolt (5/16 x 2 inches)	2	
	Washer (5/16 inch)	4	
	Lock nut (5/16 inch)	2	
<b>2</b>	Drive belt	1	Replace the deck drive belt and drive pulley
	Pulley	1	
<b>3</b>	Floor locking latch	1	Install the floor plate locking latch (for 2008 and later models)
	Carriage bolt (1/4 x 3/4 inch)	2	
	Lock nut (1/4 inch)	2	
<b>4</b>	Hood handle	1	Install the hood handle.
	Plastite screw (1/4 x 1.12 inch)	2	
	Washer (5/16 inch)	2	
	Clamp	1	
<b>5</b>	Bolt (5/16 x 1-1/4 inches)	2	Secure the belt covers.
	Retaining nut (5/16 inch)	2	
	Push nut	2	
<b>6</b>	Bolt (5/16 x 1-1/4 inches)	1	Secure the seat plate.
<b>7</b>	Bolt (5/16 x 1-1/4 inches)	1	Secure the foot rest.
<b>8</b>	Safety decal, 112-1689	1	Install the decals.
	Safety decal, 106-6754	1	

# 1


## Installing the Hood Locking Latch

### Parts needed for this procedure:

1	Latch locator bracket
1	Bolt (5/16 x 3/4 inch)
1	Lock nut (5/16 inch)
1	Locking latch
1	Hood support
2	Bolt (5/16 x 2 inches)
4	Washer (5/16 inch)
2	Lock nut (5/16 inch)

### Procedure

1. Unlatch and raise the hood. Use the prop rod to hold it in place. Locate the upper (rear) metal frame support running across the underside of the hood.
2. In the upper, left corner of the metal frame, locate the hole drilled in the face of the support. Use a drill to open the hole to accept a 5/16 inch (8 mm) fastener.
3. Install the latch locator bracket as shown in Figure 1 using a bolt (5/16 x 3/4 inch) and lock nut (5/16 inch).
4. Use a pencil to mark the hood at the center hole on the punch-out of the latch locator bracket. Remove the latch locator bracket.
5. Pilot drill a hole in the plastic hood at the marked spot and then expand the hole to a diameter of 1 inch.
6. Remove the punch-out from the latch locator. Install the latch locator bracket to the frame as in Step 3 using the bolt (5/16 x 3/4 inch) and lock nut (5/16 inch).
7. Remove the locking nut from the latch assembly.
8. Install the locking latch through the hole drilled in the hood and the punched out hole in the latch locator bracket with the catch facing the forward.
9. Install the locking nut onto the bottom of the latch to secure it in place.




G004787

**Figure 1**

- |  |                           |  |
|--|---------------------------|--|
| 1. Hole in the face of the metal frame support | 3. Latch locator bracket  | 5. Locking latch, catch facing forward |
| 2. Lock nut (5/16 inch)                        | 4. Bolt (5/16 x 3/4 inch) | 6. Locking nut                         |

10. Install the catch plate to the left hand frame member, directly below the installed latch, at the existing holes as shown in Figure 2. Secure the catch plate to the frame member with two bolts (5/16 x 2 inches), two washers (5/16 inch) and two lock nuts (5/16 inch).



G004792

**Figure 2**

- |                           |                         |
|---------------------------|-------------------------|
| 1. Left frame member      | 4. Washer (5/16 inch)   |
| 2. Catch plate            | 5. Lock nut (5/16 inch) |
| 3. Bolt (5/16 x 2 inches) |                         |

**Note:** The bolts should be approximately centered in the slots of the catch plate.

- Close the hood slowly to see if latch catches. If it does not, loosen the bolts securing the catch plate to the frame member and adjust the plate as necessary. Tighten the bolts and verify the latch catches.

# 2


## Replacing the Deck Drive Belt and Drive Pulley

### Parts needed for this procedure:

1	Drive belt
1	Pulley

### Procedure

- Lower the cutting unit to the 1 inch height of cut setting, move the throttle lever to the Slow position, stop the engine, set the parking brake, and remove the ignition key.
- Remove the belt covers from the top of the cutting unit and set the covers aside.
- Using a breaker bar or similar tool, move the idler pulley for the top belt (Figure 3) away from the top drive belt to release the belt tension and allow the belt to be slipped off the pulleys.




G004486

**Figure 3**

- |                     |                        |
|---------------------|------------------------|
| 1. Top belt         | 3. Bottom belt         |
| 2. Top idler pulley | 4. Bottom idler pulley |

- Using a breaker bar or similar tool, move the idler pulley for the bottom belt (Figure 3) away from the bottom drive belt to release the belt tension and allow the belt to be slipped off the pulleys.
- Disconnect PTO drive shaft from gearbox.
- Remove the fasteners securing the gearbox brackets to the deck mounting plate (Figure 4).




g012522

**Figure 4**

- |                        |                      |
|------------------------|----------------------|
| 1. Gearbox             | 5. Deck drive pulley |
| 2. Gearbox bracket (2) | 6. Taperlock bushing |
| 3. Lock washer         | 7. Set screw (2)     |
| 4. Bolt                | 8. Woodruff key      |

- Remove the gearbox assembly, with the drive pulley attached, from the deck.
- Remove the (2) set screws that secure the taper lock bushing to the drive pulley on the gearbox shaft (Figure 4).
- Thread one of the removed set screws into the threaded hole of the bushing (Figure 5). Tighten the set screw to loosen the bushing from the pulley hub.



**Figure 5**

1. Set screw installation position
2. Set screw removal position

# 3


## Installing the Floor Plate Locking Latch (for 2008 and later models)

### Parts needed for this procedure:

1	Floor locking latch
2	Carriage bolt (1/4 x 3/4 inch)
2	Lock nut (1/4 inch)

### Procedure

1. Raise the floor plate (Figure 6).



**Figure 6**

1. Hole in floor plate
2. Locking latch
3. Latch

10. Slide the bushing and pulley from the gearbox shaft. Locate and retrieve the woodruff key.
11. Clean the gearbox output shaft and the taper lock bushing thoroughly.
12. Position the woodruff key, new pulley and then the taper lock bushing onto the gearbox output shaft. Slide the bushing to the shoulder on shaft. Align threaded holes of pulley with non-threaded holes of bushing.
13. Lightly oil the threads of the set screws and install the screws into the threads of the pulley (Figure 5). Alternately and evenly tighten the set screws to a torque from 180 to 250 in-lb (20 to 28 N-m).
14. Fill allen recess in set screws and bushing threads with grease to prevent dirt from packing into crevices.
15. Position gearbox assembly, with drive pulley attached, onto the deck.
16. Route the new belt around the gearbox pulley, bottom spindle pulleys, and idler pulley assembly as shown in Figure 3.
17. Route the existing belt around the top spindle pulleys and idler pulley assembly as shown in Figure 3.
18. Position and secure the gearbox brackets to the deck mounting plate.
19. Connect the PTO drive shaft to the gearbox.
20. Install the belt covers.

2. Install the latch bracket to the frame using two carriage bolts (1/4 x 3/4 inch) and two lock nuts (1/4 inch) (Figure 6).
3. Insert the locking latch into the hole in the floor plate with the catch facing to the left.
4. Install the locking nuts onto the bottom of the latch to secure it in place.

**Note:** The mounting holes in the latch are slotted so the latch can be adjusted.

# 4

## Installing the Hood Handle

### Parts needed for this procedure:

1	Hood handle
2	Plastite screw (1/4 x 1.12 inch)
2	Washer (5/16 inch)
1	Clamp

### Procedure

1. Locate the hood support rail on the inside of the left side of the hood.

2. Measure up, from the support edge, along the rail 1-1/2 inches (3.8 cm) (Figure 7). Install the clamp around the rail at this location.
3. Using the clamp as a template, mark a spot in the hood and drill a 5/16 inch (8 mm) diameter hole.
4. Install a washer (5/16 inch) and plastite screw (1/4 x 1.12 inch) through the clamp and drilled hole in the hood and into the hood handle.
5. With the hood handle in the approximate position shown in Figure 7 mark the second spot to drill 4.8 inches (12.2 cm) from the initial drilled hole. Swing the hood handle out of position and drill a 0.3125 inch diameter hole at that position in the hood.
6. Install a washer onto the other plastite screw (1/4 x 1.12 inch) and through the hood. Secure the handle to the hood by tightening plastite screws.




Figure 7

- |                           |  |                                     |                         |
|---------------------------|--|-------------------------------------|-------------------------|
| 1. Hood                   | 3. Drilled hole, 5/16 inch diameter (8 mm) | 5. Washer (5/16 inch)               | 7. 4.8 inches (12.2 cm) |
| 2. 1-1/2 inches (3.81 cm) | 4. Clamp                                   | 6. Plastite screw (1/4 x 1.12 inch) |                         |

# 5

## Securing the Belt Covers

### Parts needed for this procedure:

2	Bolt (5/16 x 1-1/4 inches)
2	Retaining nut (5/16 inch)
2	Push nut

### Procedure

Perform this procedure for the right and left side belt covers.

1. Remove the hand knobs securing the belt covers to the mower deck. Remove the belt covers.
2. Install a retaining nut at the forward hole in the deck bracket.




Figure 8

Left side belt cover shown.

- |                  |                               |
|------------------|-------------------------------|
| 1. Belt cover    | 5. Bolt (5/16 x 1-1/4 inches) |
| 2. Mower deck    | 6. Hand knob                  |
| 3. Retaining nut | 7. Push nut                   |
| 4. Deck bracket  |                               |

3. Install the bolt into the belt cover using a push nut (5/16 inch). Install the belt cover with the bolt (5/16 x 1-1/4 inches). Replace the hand knob.

# 6

## Securing the Seat Plate

### Parts needed for this procedure:

1	Bolt (5/16 x 1-1/4 inches)
---	----------------------------

### Procedure

Install a bolt in the seat plate to secure it. Locate the hole in the front, right side of the seat plate, in front of the *Operator's Manual* tube (Figure 9). Install a bolt in the this hole to secure the seat plate.




Figure 9

- |   |                               |
|---|-------------------------------|
| 1. Hole in seat plate                       | 3. Right side of seat         |
| 2. Hole in foot rest (for 2007 models only) | 4. Right motion control lever |

# 7

## Securing the Foot Rest (2007 models only)

### Parts needed for this procedure:

1	Bolt (5/16 x 1-1/4 inches)
---	----------------------------

### Procedure

Install a bolt in the foot rest to secure it. Locate the hole in the right, front corner of the foot rest (Figure 9). Install a bolt in this hole to secure the foot rest (for 2007 models only).

# 8

## Installing the Decals


### Parts needed for this procedure:

1	Safety decal, 112-1689
1	Safety decal, 106-6754

### Procedure


Install each decal as follows:

1. Thoroughly clean the area where you will install the decal.
2. Dampen the area with water or mildly soapy water.
3. Peel the decal from the backing and install it in place.
4. Squeegee across the surface of the decal, starting at the center of the decal and working toward the edges, using overlapping strokes.



**Figure 10**

1. Decal 110-6754
2. Hood
3. Locking latch
4. Decal location



**Figure 11**

Install over existing decal at location shown

1. Decal 112-1689
2. Existing decal
3. Install decal 112-1689 at this location over existing decal

**Notes:**

**Notes:**



**Count on it.**