


**CE UPDATE KIT**  
**264HE & 268HE YGT Model No. 72063 & 72103**

PART NO. 93-9251 &amp; 93-9252


**INSTALLATION  
INSTRUCTIONS**
**Loose Parts**

**Note:** Use the chart below to identify parts used for assembly.

DESCRIPTION	QTY.	USE
Thread adhesive (93-9273)	1	Install on throttle high idle screw
Fan guard	1	
Flange bolt	2	Install over hydro fan

**Adjust High Idle RPM (Model No. 72063)**

1. Loosen the lock nut (Fig. 1).
2. Apply several drops of thread adhesive to screw between lock nut and control plate (Fig. 1).
3. Start engine: refer to tractor Operator's Manual, and move throttle to fast position. Using an accurate tachometer, adjust engine high idle to 2800 RPM.
4. Tighten lock nut and check engine high idle RPM setting (Fig. 1).
5. Apply several additional drops of thread adhesive to screw threads above lock nut (Fig. 1).

**Figure 1**

1. Control plate	3. High idle adjustment
2. Lock nut	4. Apply thread adhesive

## Adjust High Idle RPM (Model No. 72103)

1. Loosen the lock nut (Fig. 1).
2. Apply several drops of thread adhesive to screw between lock nut and control plate (Fig. 1).
3. Start engine: refer to tractor Operator's Manual, and move throttle to fast position. Using an accurate tachometer, adjust engine high idle to 2800 RPM.
4. Tighten lock nut and check engine high idle RPM setting (Fig. 1).
5. Apply several additional drops of thread adhesive to screw threads above lock nut (Fig. 1).




Figure 2

1. Control plate
2. Lock nut
3. High idle adjustment
4. Apply thread adhesive

## Install Fan Guard

1. Align fan guard with holes in right side of frame (Fig. 1).
2. Secure to frame with (2) flange bolts (Fig. 1).




Figure 3

1. Fan guard
2. Flange bolt